

## KEY TO *Fig. 1*

1. Bomb steering indicator.
2. Bomb/depth charge jettison control.
3. Auto-controls pressure gauge.
4. Instrument flying panel.
5. Starter and booster coil pushbuttons—port engine.
6. Propeller feathering switch—port engine.
7. Port engine speed indicator.
8. Undercarriage warning horn test pushbutton.
9. Fuel contents gauges pushbutton.
10. Windscreen wiper controls.
11. Undercarriage indicator.
12. Boost gauges (two).
13. Starboard engine speed indicator.
14. Cylinder temperature gauges (two).
15. Propeller feathering switch—starboard engine.
16. Oil tank low-level warning lights (two).
17. Starter and booster coil pushbuttons—starboard engine.
18. Pneumatic pressure gauge.
19. Fire extinguisher pushbuttons (two).
20. Air temperature gauge.
21. D.F. indicator.
22. Fuel pressure warning lights (two).
23. Pilot's call light.
24. Flare launching warning light.
25. Suction gauge.
26. Oil pressure gauges (two).
27. Oil temperature gauge—starboard engine.
28. Boost gauge reversal control.
29. Flap control lever.
30. Compass.
31. Undercarriage selector lever.
32. Rudder pedal—starboard.
33. Windscreen de-icing pump
34. Oil temperature gauge—port engine.
35. Rudder bar adjustment wheel.
36. Flap indicator.
37. Cowling gill controls (two).
38. Intercomm. microphone pushbutton.
39. Torpedo release pushbuttons (two).
40. Brake lever.
41. Brake locking slide.
42. Bomb release pushbutton.
43. Bomb doors control.
44. Landing lamps switch.
45. Bomb master switch.